

RAINWATER TANK INSTALLATION INSTRUCTIONS



In order to ensure your tank is safe and stable, please follow the below installation instructions when installing your Rotoplas rainwater tank.

- The tank site must be flat and level, the area well compacted and free from any rocks, stones and sharp objects.
- Ensure that the prepared site is at least 600mm larger in diameter than the rainwater tank.
- A reinforced concrete slab is the ideal tank pad and must be greater than the diameter than the rainwater tank.
- If a material other than concrete is used, a retaining wall or surround must be provided to prevent erosion.
- The overflow must be piped well clear of the tank to avoid undermining of the tank base.
- Ensure that a flexible hose of at least 300mm is installed after the outlet valve to absorb any shocks or movement.
- Modular tanks must be installed on a reinforced concrete slab.

